


9. Connections

AN/AE/AS/AL/ALE pumps

- S** : Suction G 1/8 or G 1/4
- N** : Nozzle outlet G 1/8
- R** : Return G 1/8 or G 1/4
- V** : Vacuum gauge port G 1/8
- P** : Pressure gauge port G 1/8
- A** : Pressure adjustment
- r** : Rotation direction
- bp** : By-pass plug for 2-pipe operation

AN/AE

Figures are for "C" shaft rotation and nozzle outlet.



AS/AL/ALE

Figures are for "C" shaft rotation and nozzle outlet.

