



FAULT LOCATION

Burner fails to start



Burner fails to start after normal operation



Delayed ignition, burners starts violently

