

Trouble shooting

Burner shuts off

Possible causes:

1. Suction leakage. Check all connections and lines.
2. The feed line can be empty. Start the burner by pushing the reset button and let it run. If the burner trips out, wait and reset. Repeat a couple of times. The burner should not run without oil for more than 5 minutes.
3. The tank is almost empty.
4. Incorrectly dimensioned suction line.

Noise from the burner pump

Possible causes:

1. Suction leakage. Check all connections and lines.
2. Too high suction head.

Fuel is not sucked up from the tank

Possible causes:

1. Large suction leakage. Check all connections and lines.
2. Too high suction head.
3. The bypass plug is not installed in the oil pump. Fit the plug.

Since today's fuel qualities place a very high demand on materials, the Tigerloop is to be replaced after 10 years.

Caution

Liquid bio fuels must not contain alcohol.

The installation must be performed by a qualified technician familiar with local codes and ordinances and licensed by proper authority where applicable.