

ERRIGAL OIL DHW - PARTS & BOM CODES

1. Oven Door - B00148AXX
2. Spin Valve - B00128AXX
3. Ashpit Door - B00150AXX
4. Fire Door - B00149AXX
5. Door Hinge - U00030BXX
6. Door Knob - U00020AXX
7. Fire Valve - G00141AXX
8. Fire Valve Clip - V00348AXX
9. Air Distribution Baffle - F00331AXX
10. Front - B00152CXX
11. Towel Rail Bracket - B00142AXX / B00143AXX
12. Towel Rail - V00077AXX
13. Door Knob Washer - Consumable
14. Door Knob Spacer - V00035AXX
15. Base Cleaning Door - B00141AXX
16. Door Knob Locking Nut
17. Door Catch - V00084AXX
18. Oven Door Panel - F00139AXX
19. Thermometer - G00029AXX
20. Oven Bottom - Q00121BXX
21. Oven Shelves - V00092BXX
22. Plinth R.H.S. - B00145AXX
23. Nameplate - B00156AXX
24. Plinth L.H.S. - B00146AXX
25. Plinth Joining Clip - Q00134AXX
26. S.I. Base Protection Plate - F00071AXX
27. Legs - B00144AXX
28. Base - Q00146BXX
29. Sheet Iron Sides - F00069AXX
30. R.H. Oven Side - Q00122BXX
31. Oven End Flue Bottom - Q00147AXX
32. Oven End Flue Top - Q00123AXX
33. Ashpit L.H.S. - Q00117AXX
34. Formed Fuel line - V00335AXX
35. Control Valve Bracket - F00341AXX
36. Control Valve Cover - V00336AXX
37. Control Knob - U00045AXX
38. Oil Control Valve - V00334AXX
39. 1/4" x 8mm Compression Fitting - W00906AXX
40. Ashpit R.H.S. - Q00116AXX
41. Flue Check - Q00129AXX
42. Grate Support Frame - Q00368AXX
43. Oven Back - Q00128BXX
44. Flue Back - Q00119BXX
45. L.H. Oven Side - Q00125BXX
46. Back Sealing Plate - Q00120AXX
47. Small Back Panel - F00056BXX
48. Oven Top - Q00235CXX
49. Direct Damper - Q00542AXX
50. Ashpit Back - Q00115BXX
51. R.H. Window Frame - B00384AXX
52. Viewing Glass Frame - B00191AXX
53. Viewing Glass - T00035AXX
54. L.H. Window Frame - B00385AXX
55. Superette Boiler - F00330AXX
56. Hob - B00292BXX
57. Hob Rod Caps - W00923AXX
58. Simmering Plate - Q00019AXX
59. Flue Deflector Plate - B00386AXX
60. Hotplate - Q00543AXX
61. Bonnet Spin Valve - B00201AXX
62. Bonnet Door - B00200AXX
63. Bonnet - B00198BXX
64. Back Outlet Adaptor - B00204AXX
65. Bonnet Blanking Plate - B00202AXX
66. Bonnet Top Spigot - B00199AXX
67. Boiler Rest - Q00040AXX
68. Large Back Panel - F00062BXX
69. Cleaning Cup - Q00137AXX
70. Burner Stand - Q00371AXX
71. 1/4" x 8mm Compression Elbow - W00905AXX
72. Burner Pot Elbow Adaptor - W00940AXX
73. Carton Leg Assembly - V00592AXX
74. Bonnet Gasket - P00018AXX
75. Centre Wall Cap - Q00370AXX
76. 8mm Olive - Consumable
77. 8mm Compression Nut - Consumable
78. Burner - Q00372AXX
79. Wicks - V00186AXX
80. Burner Shells - F00334AXX / F00335AXX / F00336AXX / F00337AXX / F00338AXX / F00339AXX
81. Burner Lid - F00340AXX
82. Burner Baffle - F00333AXX
83. Burner Support Rod - V00333AXX

ERRIGAL OIL DHW EXP VIEW

